




1. A system with a counter-weight is moved in position.




2. The top octagonal section is attached.




3. The weight is moved sideways.




4. The top octagonal section of the forward shield is removed.




4. The top octagonal section of the forward shield is removed.



4. The top octagonal section of the forward shield is removed.




4. The top octagonal section of the forward shield is removed.







5. The bottom octagonal section of the forward shield is lowered.




5. The bottom octagonal section of the forward shield is lowered.




5. The bottom octagonal section of the forward shield is lowered.




6. The bottom octagonal section of the forward shield is moved sideways and into the reach of the crane.




7. The bottom octagonal section of the forward shield is removed.




7. The bottom octagonal section of the forward shield is removed.



7. The bottom octagonal section of the forward shield is removed.




4. The bottom octagonal section of the forward shield is removed.







8. The top back core section is removed.




8. The top back core section is removed.




8. The top back core section is removed.




8. The top back core section is removed.




69 The HF truck is removed.




9. The HF truck is removed.



9. The HF truck is removed.




9. The HF truck is removed.







10. The large muon wheel is moved forward.




10. The large muon wheel is moved forward.




10. The large muon wheel is moved forward.




10. The large muon wheel is moved forward.




11. The front top core section is removed.




11. The front top core section is removed.



11. The front top core section is removed.




11. The front top core section is removed.







11. The front top core section is removed.




11. The front top core section is removed.




12. The rotated HF truck is installed.




12. The rotated HF truck is installed.




12. The rotated HF truck is installed.




12. The rotated HF truck is installed.



13. The bottom core section is moved sideways.




14. The bottom core section is lifted to the surface.






14. The bottom core section is lifted to the surface.



14. The bottom core section is lifted to the surface.



14. The bottom core section is lifted to the surface.

